

INSTALLATION GUIDE

PAROC® PRO MAT WR 350 ALUCOAT
PAROC® PRO MAT WR 640 ALUCOAT
PAROC® PRO MAT WR 660 ALUCOAT

* Named in the brochure as mat
* Product available without additional [water repellent](#) protection




PAROC®

PAROC® PRO MAT WR ALUCOAT

Non-combustible stone wool mat with AluCoat facing and outstanding water repellency designed for industrial applications. The PAROC® Pro Mat WR AluCoat is for thermal insulation purposes when insulating flat or irregularly shaped equipment.




Data sheets





APPLICATION

- Thermal insulation of flat or irregularly shaped equipment
- For thermal insulation purposes when insulating flat or irregularly shaped equipment





PAROC® PRO MAT WR 350 ALUCOAT TECHNICAL SPECIFICATIONS

- AGI designation code: 10.06.99.99.50
- CE designation code:
MW-EN 14303-T2-ST(+)-350-WS1-MV2-CL10





PAROC® PRO MAT WR 640 ALUCOAT TECHNICAL SPECIFICATIONS

- AGI designation code: 10.06.99.99.80
- CE designation code:
MW-EN 14303-T2-ST(+)-640-WS1-MV2-CL10



PAROC® PRO MAT WR 660 ALUCOAT TECHNICAL SPECIFICATIONS

- AGI designation code: 10.06.99.99.10
- CE designation code:
MW-EN 14303-T2-ST(+)-660-WS1-MV2-CL10



ACCESSORIES



Data sheets



PAROC® HVAC ALUCOAT TAPE
Reinforced aluminum foil tape with pressure sensitive, low temperature acrylic adhesive, siliconized release paper liner and AluCoat printing.



PAROC® HVAC ALU TAPE
Reinforced aluminum foil tape with low temperature acrylic adhesive, siliconized release paper liner and AluCoat printing.



PAROC® PRO KNIVES
Particularly suitable for cutting Paroc products

INSTALLATION INSTRUCTIONS



STEP 1

Cut the mat with a knife (e. g. PAROC® Pro Knife) to the appropriate length equal to the external circumference of the insulated duct:

- for **circular ducts**:
 $\pi \times [D + 2 \times \text{insulation thickness}]$
- for **rectangular ducts**:
 $[2 \times \text{length side A}] + [2 \times \text{length side B}] + 8 \times \text{thickness insulation plus add about 2-3 cm.}$

STEP 2

Place the mat on the **circular duct** with the AluCoat aluminium foil on the outside so that its ends hang loosely.

STEP 2A

Press both ends of the mat to the surface of the duct and connect them with PAROC® Hvac AluCoat Tape or PAROC® Hvac Alu Tape.

STEP 3

Apply welding pins on the surface of the **rectangular duct** (8-10 pieces per 1 m²), then place the mat on the pins and secure it against slipping with self-locking clips. Cut the ends of the pins above the cap.

STEP 3A

For rectangular ducts, the insulation should touch the frames connecting the individual duct elements. The joints, insulated this way on both sides and clean, should be fixed along the perimeter with self-adhesive PAROC® Hvac AluCoat Tape or PAROC® Hvac Alu Tape overlapping is recommended.

STEP 4

In case of tension or compression on the AluCoat Aluminium foil and for insulation of ducts bigger than 200 mm diameter, it is absolutely necessary to add metal bands, ensuring that they are not too tight and will not cut or damage the facing.

Notes:

- The thickness of the insulation should be designed appropriately according to the operating parameters of the installation and the conditions in the room, otherwise the joints may be damaged.
- PAROC® Pro Mat WR AluCoat can be used for all types of indoor installations appropriately to maximum service temperature.
 - When insulating outdoor installations, additional protection is needed.
- When high insulation thickness is required, PAROC® Pro Mat (WR) AluCoat can be installed in two layers, placing the joints of mat fragments away from each other to prevent thermal bridges.
- Do not walk on the previously made insulation during the installation process, as this may cause damage to it.
- Dry and clean the AluCoat surfaces well by wiping the aluminum side with isopropanol before fixing them on the mat ends in order to obtain a good quality of the joints. The self-adhesive tape should be firmly pressed with the help of a spatula.
- Head Pins must be insulate.

STEP 5

Next, add the mat to the duct, following the instructions given in steps 1-4.

STEP 7

The ends of insulation should be covered by a cuff, adjusted to the thickness of the mat.

STEP 6

Clean the surface and connect the joints using PAROC® Hvac AluCoat Tape or PAROC® Hvac Alu Tape

STEP 8

Before installing the mat, cut out holes for all kinds of elements on the duct, such as fittings, valves, tees, and fasteners etc.

CONTACT



PAROC SALES OFFICES AND CONTACTS

Headquarter / Finland

Paroc Group Oy / Paroc Oy Ab
P.O. Box 240
FI-00181 Helsinki, Finland
Energiakuja 3
Tel. +358 46 876 8000
Email: [Contact us in Finland](#)

Estonia

AS Paroc
Pärnu mnt 158
EE-11317 Tallinn, Estonia
Tel. +372 651 8100
Email: [Contact us in Estonia](#)

The United Kingdom / Ireland

Owens Corning Insulation (UK) Ltd
31-35 Kirkby Street
London EC1N 8TE
The United Kingdom
Email: [Contact us in UK & Ireland](#)

Denmark

Paroc Danmark Filial af PAROC AB
Helsingør Erhvervspark A/S
H P Christensensvej 1
DK-3000 Helsingør
Tel. +45 49 12 10 00
Email: [Contact us in Denmark](#)

Latvia

SIA Paroc
Vienības gatve 109
Rīga, LV-1058, Latvia
Tel. +371 7 339053
Email: [Contact us in Latvia](#)

Norway

Paroc AB Norge
Rosenholmveien 25
NO-1414 Trollåsen, Norway
Tel. +47 22 64 59 00 / 01
Email: [Contact us in Norway](#)

Germany / Switzerland / Austria

Paroc GmbH
Heidenkampsweg 51
D-20097 Hamburg, Germany
Tel. +49 40 33 49 60000
Email: [Contact us in DACH area](#)

Lithuania

UAB Paroc
Savanoriu 124
03153 Vilnius, Lithuania
Tel. +370 5 2740 000
Email: [Contact us in Lithuania](#)

Sweden

Paroc AB
SE-541 86 Skövde, Sweden
Visiting address: Bruksgatan 2
Tel. +46 500 469 000
Email: [Contact us in Sweden](#)

Belgium / The Netherlands / France

Email: [Contact us in Belgium French](#)
Email: [Contact us in Belgium Dutch](#)
Email: [Contact us in Netherlands](#)
Email: [Contact us in France](#)

Poland

Paroc Polska sp. z o.o.
ul. Gnieźnińska 4
62-240 Trzemeszno, Poland
Tel. +48 61 468 21 90
Email: [Contact us in Poland](#)

INTERNATIONAL CONTACTS

Business Director Industry

Peter van Zandbergen

peter.van.zandbergen@owenscorning.com

Segment Manager Industry

Fredrik Saterborn

fredrik.saterborn@owenscorning.com

Technical Support

Craig Treanor

craig.treanor@owenscorning.com

Disclaimer

The information relating to the products and systems contained in this communication ("Information") is accurate and reliable to the best of our knowledge as of its date issued and is subject to change without prior notice. No guarantee of accuracy is given or implied.

Since Paroc has no control over installation workmanship, accessory materials or conditions of application, no express or implied warranty of any kind, including those of merchantability or fitness for a particular purpose or course of performance or usage of trade, is made as to the performance of an installation containing Paroc products.

While the Information in this communication may relate to the technical application of certain Paroc products, it is in no event to be considered as technical advice on the basis of which Paroc may incur any liability.

User is solely responsible for determining whether a Paroc product is fit for a particular purpose and suitable for user's method of use or application.

Users of the provided Information assume full responsibility for all concept/design decisions made relating to the suitability of use.

Users must rely on their own judgment or that of a concept/design professional when determining how to best apply the data provided.

Users agree that Paroc is under no obligation to provide additional details, testing or test data on its behalf.

Liability of Paroc, if any, is strictly limited to replacement of product. In no event shall Paroc be liable for any other damages arising because of product failure, whether incidental, special, consequential or punitive, regardless of the theory of liability upon which any such damages are claimed.

Applications: March 2026

1263TIEN0326

© Paroc 2026

